



Be a professional reconer!

JBL EON 15 G2 and JBL EON Power 15 and JBL EON 10 G2 Recone Instruction Kit



Step 1. – Place Cabinet on back and remove the four (4) Phillips screws fastening the grill.



Step 2. – Use a flat screw driver and remove the four (4) plastic grommets [please note: two of the grommets are shorter than the other two, keep in mind where to replace them when re assembling]



Step 3. – Use a carpet knife and remove the old cone assembly from speaker frame.



Step 4. – Dry fit replacement kit to ensure proper fit



Step 5. – apply a bed of glue where spider and cone edge will fit.



Step 6. – Insert kit in frame, ensuring leads are at the bottom of the frame.



Step 7. – Press kit into glue and insert plastic shim inside voice coil

LET DRY FOR 24 TO 36 HOURS



Step 8. – Remove plastic shim and push leads onto terminals located in the center of the magnet.



Step 9. – Glue dust cap in place



Step 10. – Apply Dampening solution to cone's edge. Place a can of soda on the dust cap to hold it in place while it dries.



Step 11. – Use a pointed tool [such as an ice pick] to reopen holes for the grommets.

Step 12. – Replace grommets and grill.